

Product Specification

tSENSE (Disp)

CO₂-, Temperature- and RH-sensor in a housing
with colour touch display



General

tSENSE (Disp) is an advanced and versatile 3-in-1 sensor in a housing, designed for installation in the air-conditioned zone. It measures CO₂ concentration, temperature and humidity in the ambient air accurately without need for additional compensation – true read. The data transmits to a BMS system or stand-alone controller using industry standard output signals and communication protocols.

Complies with ASHRAE standard 189.1 (± 50 ppm @ 1000ppm of measured CO₂ value)

Key technical specification

Item	tSENSE (Disp)
------	---------------

General performance

Operating environment	Residential, and commercial spaces
CO ₂ measurement range	0 – 2000ppm _{vol} .
Temperature measurement range	0 – 50°C
Relative humidity measurement range	0 – 100%RH
Storage environment	Non condensing, non-corrosive environment
Storage temperature range	-30 – 70°C
Communication	Modbus (MB) or BACnet (BAC) protocol over RS485
Linear analogue outputs	Voltage 0 – 10V.
Digital output	Relay
Warm up time	≤1min. (@ full specs 15min)
Life expectancy	>15 years
Self-Diagnostics	Complete function check, red LED and LCD error indication (display mode)
Display	Configurable colour LCD with CO ₂ (ppm), Temperature (°C) and Humidity (%RH)
Maintenance	Maintenance-free when using Senseair ABC algorithm (<i>Automatic Baseline Correction</i>). ¹

CO₂ measurement

Operating principle	Non-dispersive infrared (NDIR)
Sampling method	Diffusion
Response time (T _{1/e})	<3 min diffusion time
Measurement period	15s
Measurement range	0 – 2000ppm _{vol}
Accuracy	±50ppm @ (1000ppm _{vol} , 17 – 28°C and 30 – 60%RH) Typical full range: ±30ppm ±3% of measured ^{2, 3}

¹ ABC is enabled in default configuration

² Accuracy is specified over operating temperature range 0 – 50°C and relative humidity 0 – 95%RH non condensing at normal pressure 101.3 kPa. Specification is referenced to certified calibration mixtures. Uncertainty of calibration gas mixtures (±1% currently) is to be added to the specified accuracy for absolute measurements.

³ Accuracy is defined after minimum three weeks of continuous operation with ABC enabled (default configuration)

Key technical specification

Item	tSENSE (Disp)
Pressure dependence	+1.58% reading per kPa deviation from normal pressure 101.3kPa

Temperature measurement

Operating principle	Bandgap temperature sensor
Temperature measurement range	0 – 50°C
Temperature measurement accuracy	±0.5°C (@ 17 – 28°C), ±1.0°C (@ 0 – 50°C)
Repeatability	±0.25°C (@ 17 – 28°C)
Response time	<6min (Air velocity of 0.15m/s)
Measurement period	15s

Relative humidity measurement

Operating principle	Capacitive humidity sensor
Relative humidity measurement range	0 – 100%RH
Relative humidity measurement accuracy	±5%RH (@ 20 – 80%RH)
Hysteresis	±1%RH (@ 20 – 80%RH)
Annual drift	<±0.5%RH
Repeatability	±0.25°C (@ 17 – 28°C)
Response time	<6min (Air velocity of 0.15m/s)
Measurement period	15s

Electrical / Mechanical

Power supply	12VDC, 24VDC, or 24VAC ±20%, 50/60Hz
Power consumption	<0.6W
Peak power consumption	<2W
Wiring connections	Screw terminal, max 1.5mm ² Containing: Power, GND, Out1, Out2, Out3, RS485, and passive temperature or relay (just one of them can be available).
Dimensions	125 x 85 x 22 mm (Length x Width x Height)

Key technical specification

Item	tSENSE (Disp)
Dimensions display	49 x 37 mm (Length x Width)
Linear analogue outputs protection	PTC-fuses (auto reset), short-circuit safe
Linear analogue outputs conversion accuracy	±2% of reading ±20mV
Linear analogue outputs signal	Voltage output 0–10V, $R_{out} < 100\Omega$, Load: $>5k\Omega$
Linear analogue outputs resolution	10-bits, 10mV steps, 0.1% steps of full ppm / °C / %RH range

Table 1: Key technical specification for tSENSE (Disp)

Terminal descriptions

The table below specifies terminals and I/O options available on the tSENSE (Disp)

Functional group	Descriptions and ratings
G+:	Power supply voltage may be AC or DC. Positive pole of DC power supply shall be connected to G+. Sensor performs half wave rectification of supplied AC voltage. Power supply lines are protected by a varistor and fuse from voltage spikes and over voltage. Nominal specification: 12VDC, 24VDC, or 24VAC ±20%, 50/60Hz Power consumption: <0.6W
G0:	Connected to sensor's ground. Negative pole connection for DC power supply

Outputs The outputs can be configured with PC software UIP (version 5 or higher). See information at <https://senseair.com/download>

Linear analogue outputs:

Out1: CO ₂	Buffered linear output 0–10V, corresponds to 0–2000ppm _{vol} . Resolution: 10-bits, 10mV steps.
Out2: Temperature (T)	Buffered linear output 0–10V, corresponds to 0–50°C. Resolution: 10-bits, 10mV steps.
Out3: Relative humidity (RH)	Buffered linear output 0–10V, corresponds to 0–100%RH. Resolution: 10-bits, 10mV steps.
CO ₂ /T /RH	Configurable via touch display.

Digital output:

Relay (RL)	On $\geq 1000\text{ppm}_{vol}$ CO ₂ , Off $\leq 900\text{ppm}_{vol}$, CO ₂ . Form C / DPDT, I_{max} : 1A/50VAC/24VDC
Input Source CO ₂ / T/ RH	Configurable via touch display.

Serial Communication

RS485	Modbus (MB) or BACnet (BAC) protocol
-------	--------------------------------------

Table 2: I/O notations for tSENSE (Disp)

Maintenance

The tSENSE (Disp) is basically maintenance free. An internal self -adjusting calibration function takes care of normal long term drift associated to the CO₂ sensor. To secure the highest accuracy, a time interval of five years is recommended between CO₂ calibrations, unless some special situations have occurred.

Calibration option	CO ₂ concentration level
Background calibration	Assuming 400ppm CO ₂ sensor exposure
Zero Calibration	Assuming 0ppm CO ₂ sensor exposure

Table 3: Calibration options for the tSENSE (Disp)

The calibration options can be achieved by Senseair software (UIP5) which can be free downloaded at <https://senseair.com/download>, or by Modbus communication (more information in document TDE0103 which is available at Senseair website), or using calibration option on tSENSE display (more information in document UMA0176 which is available at Senseair website).

tSENSE (Disp) has a manual option to achieve the background calibration by pushing the blue button which you can find in the bottom side of the housing for 15 seconds in fresh air (400ppm CO₂) more information available in document UMA0176.

Self-diagnostics

The system contains complete self-diagnostic procedures. A full system test is executed automatically every time the power is turned on. In addition, constantly during operation, the sensor probes are checked against failure by checking the valid dynamic measurement ranges. All EEPROM updates, initiated by the sensor itself, as well as by external connections, are checked by subsequent memory read back and data comparisons. These different system checks return error bytes to the system RAM. The error codes are available by Modbus / BACnet protocols on RS485. Out of Range is the only bit that is resets automatically after return to normal state. All other error bits should be reset manually after return to normal by power off/on.

Sensor error codes and action plan

Bit #	Error code	Error description	Suggested action
0	CO ₂ sensor: com error	Not able to communicate with CO ₂ sensor module.	Restart the sensor by power OFF – power ON. Contact local distributor.
1	CO ₂ sensor: CO ₂ measure error	CO ₂ measurement error.	Background calibration (for more details please read page 15 in UMA176 document which you can find at Senseair website). Contact local distributor. See note 1!
2	CO ₂ sensor: temperature measure error	Temperature measurement error.	Restart the sensor by power OFF – power ON. Contact local distributor
3	RH/T sensor: com error	Not able to communicate with RH/T sensor module	
4	RH/T sensor: RH measure error	Relative humidity measurement error	
5	RH/T sensor: T measure error	Temperature measurement error, sensor will use CO ₂ sensor temperature if RH/T temperature is unavailable, S_Temp will be set to NTC_Temp	
6			
7			
8	Output configuration error	Error in output configuration, output is still updated.	Check connection and loads of outputs. Check detailed settings and configuration with UIP software ver.5 or higher. Contact local distributor.
9	Memory error	One or several bytes of sensors parameters memory (settings) are corrupt	Restart the sensor by power OFF – power ON. Contact local distributor.

Table 4: Sensor error codes and action plan

Note 1. Any probe is out of range. It occurs, for instance, during over-exposure of CO₂ sensor, in which case the error code will automatically reset when the measurement values return to normal. It can also indicate the need of zero calibration. If the CO₂ readings are normal, and still the error code remains, any other sensor probe mounted (if any) can be defect, or the connection to this probe is broken.

If several errors are detected at the same time the different error code numbers will be added together into one single error code!

www.senseair.com