

Installation Manual

Senseair Go

Alcohol interlock for Vehicles



Table of contents:

- 1. Items..... 3
- 2. Safety instructions and warning notices 4
 - 2.1. General 4
 - 2.2. Warning notices..... 4
- 3. HW Installation 4
 - 3.1. General Precautions 4
 - 3.2. Accessbox wiring and connections to the vehicle..... 5
 - 3.3. Mounting 10
 - 3.4. Securing cables and wiring 10
 - 3.5. Installation of Handset 13
 - 3.6. Optional installation of RFID reader 15
 - 3.7. Optional Ethernet cable connection 16
- 4. Functional test..... 16
- 5. Related documents..... 17



1. Items




Figure 1: Senseair Go items overview

Table 1: Senseair Go items

Pos.	Item name	Item number	QTY
1	Handset	008-15-0012	1
2	Accessbox Senseair Go	900-00571	1
3	Holder	426-00176	1
4	Handset Cable	840-00020	1
5	Power Cable	840-00035	Optional
6	Input Communication Cable	840-00036	Optional
7	Relay Cable	840-00037	Optional
8	RFID Reader	820-00045	Optional (Holder included)


2. Safety instructions and warning notices

2.1. General

Installation shall only be performed by an authorised service centre or qualified personnel in accordance with these installation instructions. Installation requires basic knowledge of 12/24 V vehicle electrical systems. It is recommended that technicians hold an ASE electrical certification or possess an equivalent level of experience. Vehicle-specific service manuals shall be consulted as required.


Do not disassemble or modify the product, and do not install non-approved parts. Unauthorised modifications may void the warranty of the device and/or the vehicle.

2.2. Warning notices


 The warning symbol indicates a potentially hazardous situation which, if not avoided, may result in death, serious injury, or unsafe operation.


3. HW Installation


3.1. General Precautions


 Failure to use correct tools, methods, or procedures when modifying the vehicle electrical system may result in serious damage to the vehicle and/or serious injury or death.

 Do not exceed the specified electrical ratings.

 The Senseair Go shall only be permanently installed after agreement with the vehicle owner on the installation location. Ensure that the mounting location does not interfere with normal vehicle operation or compromise the safety of the driver or passengers.

 Installation shall only be performed with the vehicle switched off. The battery shall be disconnected to prevent damage to the vehicle or the Senseair Go during installation.

 Do not probe, solder, cut, or otherwise interfere with safety-critical vehicle systems, including but not limited to ABS, airbags, steering, or driver assistance systems.

 For hybrid (HEV) or battery electric vehicles (BEV), do not probe, solder, cut, or otherwise interact with any components of the high-voltage traction battery system. High-voltage components are typically identified by orange cables, conduits, or markings.

⚠ Solderless connectors may be used for all connections; however, soldered connections provide improved mechanical reliability and reduce the risk of accidental disconnection. Soldering is recommended in humid environments or for permanent installations.

3.2. Accessbox wiring and connections to the vehicle








Figure 2: Wiring diagram (basic installation)



Connections to Senseair Go items are not shown in the figure. They are specified in Table 2. Colours of the wires, shown in the diagram, correspond to optional cables (see Figure 2).

Table 2: Accessbox connection details

Connector	Description	Comment																					
<p>J1</p>	<p>Relay terminal block, 6-position (SPT 2,5/ 6-H-5,0 Phoenix Contact)</p>  <table border="1" data-bbox="384 752 1037 1599"> <thead> <tr> <th>Pin #</th> <th>Pin name</th> <th>Feature</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Relay1_COM</td> <td>Relay with normally open (NO) contact. The contact closes upon user log-in.</td> </tr> <tr> <td>2</td> <td>Relay1_NO</td> <td>The contact opens upon user log-out or loss of power.</td> </tr> <tr> <td>3</td> <td>Relay2_COM</td> <td>Relay with normally open (NO) contact.</td> </tr> <tr> <td>4</td> <td>Relay2_NO</td> <td>The contact closes for a configurable time interval (from 1.5 to 300 sec) when a negative test result is detected.</td> </tr> <tr> <td>5</td> <td>Relay3_COM</td> <td>Relay with normally open (NO) contact.</td> </tr> <tr> <td>6</td> <td>Relay3_NO</td> <td>The contact closes for a configurable time interval (from 1.5 to 300 sec) when a positive test result is detected.</td> </tr> </tbody> </table>	Pin #	Pin name	Feature	1	Relay1_COM	Relay with normally open (NO) contact. The contact closes upon user log-in.	2	Relay1_NO	The contact opens upon user log-out or loss of power.	3	Relay2_COM	Relay with normally open (NO) contact.	4	Relay2_NO	The contact closes for a configurable time interval (from 1.5 to 300 sec) when a negative test result is detected.	5	Relay3_COM	Relay with normally open (NO) contact.	6	Relay3_NO	The contact closes for a configurable time interval (from 1.5 to 300 sec) when a positive test result is detected.	<p>Recommended operating limits per relay channel:</p> <p>Resistive loads (make/break allowed):</p> <ul style="list-style-type: none"> 12 V systems: ≤ 12 A switching / 15 A continuous carry 24 V systems: ≤ 6 A switching / 10 A continuous carry <p>Inductive/motor/solenoid loads (suppression required):</p> <ul style="list-style-type: none"> 12 V systems: ≤ 6 A switching / 10 A carry 24 V systems: ≤ 3 A switching / 7 A carry <p>⚠ Unsuppressed inductive loads not permitted. Fuse upstream.</p> <p>Suggested cable: 840-00037</p> <p>Nominal cross section of the connected wire: 2.5 mm²</p>
Pin #	Pin name	Feature																					
1	Relay1_COM	Relay with normally open (NO) contact. The contact closes upon user log-in.																					
2	Relay1_NO	The contact opens upon user log-out or loss of power.																					
3	Relay2_COM	Relay with normally open (NO) contact.																					
4	Relay2_NO	The contact closes for a configurable time interval (from 1.5 to 300 sec) when a negative test result is detected.																					
5	Relay3_COM	Relay with normally open (NO) contact.																					
6	Relay3_NO	The contact closes for a configurable time interval (from 1.5 to 300 sec) when a positive test result is detected.																					

Connector	Description	Comment
J2	<p>USB I/O Receptacle, Type A, Dual Port Stacked</p>  <p>Used for:</p> <ul style="list-style-type: none"> • Configuration of SafeStart with identified usage via an external RFID reader. • Modification of settings using the Senseair Alcohol Screener Configurator. 	RFID reader: 820-00045
J3	<p>RJ45 Connector, Single Port, 1 x 1, Jack</p>  <p>Used for internet connection</p>	Used exclusively for SafeStart communication

Connector	Description	Comment																					
J4	<p>Digital Inputs Connector (16-pin)</p> <p>(Micro-Fit 3.0 series number: 43045 Molex)</p>  <table border="1"> <thead> <tr> <th>Pin #</th> <th>Pin name</th> <th>Feature</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>In1</td> <td> Digital input "Start test" ⁽¹⁾: <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V </td> </tr> <tr> <td>2</td> <td>In2</td> <td> Digital input "Motor on" ⁽¹⁾: <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V </td> </tr> <tr> <td>3</td> <td>In3</td> <td> Digital input "Log out" ⁽¹⁾: <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V </td> </tr> <tr> <td>4...8</td> <td>-</td> <td>Not used</td> </tr> <tr> <td>9...15</td> <td>GND</td> <td>Ground</td> </tr> <tr> <td>16</td> <td>-</td> <td>Not used</td> </tr> </tbody> </table> <p>⁽¹⁾ Configurable</p> <p>Digital inputs In1...In3 characteristics:</p> <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V Input current: 60...160 μA (12–32 B) 	Pin #	Pin name	Feature	1	In1	Digital input "Start test" ⁽¹⁾ : <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V 	2	In2	Digital input "Motor on" ⁽¹⁾ : <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V 	3	In3	Digital input "Log out" ⁽¹⁾ : <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V 	4...8	-	Not used	9...15	GND	Ground	16	-	Not used	<p>Suggested cable: 840-00036</p> <p>Suggested mating part: 430251600 Molex</p> <p>Nominal cross section of the connected wire: 0.5 mm²</p>
Pin #	Pin name	Feature																					
1	In1	Digital input "Start test" ⁽¹⁾ : <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V 																					
2	In2	Digital input "Motor on" ⁽¹⁾ : <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V 																					
3	In3	Digital input "Log out" ⁽¹⁾ : <ul style="list-style-type: none"> Logic HIGH (1): 9 ... 32 V Logic LOW (0): 0 ... 3 V 																					
4...8	-	Not used																					
9...15	GND	Ground																					
16	-	Not used																					

Connector	Description	Comment															
J5	Handset connector (6-pin) (Micro-Fit+ series number: 212528 Molex) 	Only cable 840-00020 is permitted for connection to this connector															
J6	Power connector (4-pin) (Mega-Fit series number: 172064 Molex)  <table border="1" data-bbox="384 1010 1037 1742"> <thead> <tr> <th>Pin #</th> <th>Pin name</th> <th>Feature</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>GND</td> <td>Ground</td> </tr> <tr> <td>2</td> <td>GND</td> <td>Ground</td> </tr> <tr> <td>3</td> <td>Wake-up</td> <td> Digital input "Wake-up": <ul style="list-style-type: none"> Logic HIGH (1): 8 ... 32 V Logic LOW (0): 0 ... 3 V Input current: $I_{in} = (V_{in} - 1.2 V) / 10 k\Omega$ Typical values: <ul style="list-style-type: none"> 0.7 mA @ 8 V 1.1 mA @ 12 V 2.3 mA @ 24 V 3.1 mA @ 32 V </td> </tr> <tr> <td>4</td> <td>12/24 VDC</td> <td>Senseair Go power supply input</td> </tr> </tbody> </table>	Pin #	Pin name	Feature	1	GND	Ground	2	GND	Ground	3	Wake-up	Digital input "Wake-up": <ul style="list-style-type: none"> Logic HIGH (1): 8 ... 32 V Logic LOW (0): 0 ... 3 V Input current: $I_{in} = (V_{in} - 1.2 V) / 10 k\Omega$ Typical values: <ul style="list-style-type: none"> 0.7 mA @ 8 V 1.1 mA @ 12 V 2.3 mA @ 24 V 3.1 mA @ 32 V 	4	12/24 VDC	Senseair Go power supply input	Suggested cable: 840-00035 Suggested mating part: 1700010104 Molex Nominal cross section of the connected wire: 2.5 mm ²
Pin #	Pin name	Feature															
1	GND	Ground															
2	GND	Ground															
3	Wake-up	Digital input "Wake-up": <ul style="list-style-type: none"> Logic HIGH (1): 8 ... 32 V Logic LOW (0): 0 ... 3 V Input current: $I_{in} = (V_{in} - 1.2 V) / 10 k\Omega$ Typical values: <ul style="list-style-type: none"> 0.7 mA @ 8 V 1.1 mA @ 12 V 2.3 mA @ 24 V 3.1 mA @ 32 V 															
4	12/24 VDC	Senseair Go power supply input															

3.3. Mounting

Step 1: Select a suitable mounting location in the vehicle based on the dimensions of the Accessbox Senseair Go (hereinafter referred to as the Accessbox). Ensure a minimum clearance of 20 mm around the enclosure for heat dissipation and 30 ... 50 mm in front of the connectors to allow for proper cable installation.

⚠ Do not install the Accessbox with the connectors facing upward in wet environments. Although the Accessbox is rated IP54 and protected against light water spray, this orientation may allow water to accumulate at the connectors and enter the enclosure. Failure to comply with this instruction may result in damage to the Accessbox and/or an increased risk of electric shock.


Step 2: Secure the Accessbox using four (4) bolts or self-tapping screws, M5. Two (2) fasteners shall be installed on each side mounting flange, evenly spaced.

3.4. Securing cables and wiring

All connectors specified in Table 2 must be fully inserted with the latches engaged.

Each cable in the installed configuration shall exit the Accessbox perpendicular to the connector along all axes to prevent lateral stress on the connectors. The cables shall be secured within 30 ... 50 mm from the connector interface, as shown in Figure 3.

A minimum bending radius shall be maintained in accordance with AEIC and ICEA standards. Max. single cable outer diameter within the assembly



Cable Construction	Formula
Single Cable	$R_{MIN} = F \times OD$
4 or More Cable Assembly	$R_{MIN} = F \times (2.414 \times OD)$

- R_{MIN} – Minimum allowable bend radius
- Factor (F) – Multiplication factor for the assembly design
- OD – Max. single cable outer diameter within the assembly

Figure 3: Cable Routing and Securing Recommendations

⚠ Before applying power, verify that all safety precautions are taken. Make all connections to the unit before applying power.

⚠ To minimise the risk of electric shock, the instrument shall be properly grounded. The Accessbox must be powered via a DC supply using a grounded cable, with the ground conductor connected to chassis ground.

Step 3: Find the positive (+) terminal or source of constant 12–24 VDC power. Disconnect the negative (-) battery terminal, to prevent damage to the vehicle during installation.

Step 4: Protect the power connection point with a 10 A fuse. Never connect a cable directly to the battery. Connect J6 pin 4 to Fuse F1, J6 pin 1 to vehicle ground (see details in Table 2 and Figure 2).

Step 5: Connect pin 2 of connector J6 to vehicle ignition (terminal 15) (see details in Table 2 and Figure 2).


Step 6: Plug in the connector side of the power cable into the Accessbox (see Figure 2, connector J6 and details in

Table 2).

Step 7: Connect the contacts of Relay0 in series with the vehicle starter solenoid circuit (terminal 50) (see connector J1 details in Table 2).

Step 8: Connect pin 2 of connector J4 to vehicle ignition (terminal 15) and pin 9 of connector J4 to vehicle ground (see details in Table 2 and Figure 2).

Connect the cable-side connector of the Input Communication Cable to the Accessbox (connector J4, refer to Figure 2 and Table 2).

 If both the power pin and the wake-up pin are powered, the Senseair Go remains active, which may result in battery discharge.

3.5. Installation of Handset



Figure 4: Holder installation

Note: Diameter of the screws is 5.0 mm, pan head style. The specific screw type shall be selected based on the mounting wall material, wall thickness, and applicable installation conditions.




Figure 5: Handset installation

Note: Cable clamp is recommended and not included in the delivery.

It is recommended to install the handset in such a way that the user can perform a breath test without removing the handset from the holder.




Figure 6: Handset Cable Connection

3.6. Optional installation of RFID reader

Connect the USB cable to either of the USB ports (J2) on the Accessbox.




Figure 7: RFID Holder installation

Note: Diameter of the screws is 5.0 mm, pan head style. The specific screw type shall be selected based on the mounting wall material, wall thickness, and applicable installation conditions.

3.7. Optional Ethernet cable connection


Connect the Ethernet cable to connector J3 on the Accessbox.


4. Functional test

Verify the functionality of the device in accordance with the Senseair Go user manual. Example display messages are shown in English; Swedish and Japanese versions are also available. For SafeStart functional testing, a customer identification RFID tag or card is required.


1. The Senseair Go powers up when the vehicle ignition (terminal 15) is switched on or via a digital input (e.g. interior lighting activated or vehicle unlocked).
2. The handset display shows one of the following messages, depending on the configuration:

"Ready", "Press button to start", or "Scan your RFID tag".



3. The engine must not be started until the test procedure has been completed.
4.  No error messages shall be present on the vehicle instrument cluster.
5. Perform a breath test.
6. For a negative test result, the handset display indicates:

"Passed", followed by "Logged in", and the remaining Free Start Time shown at the bottom of the display, depending on configuration and installation.



7. The engine can now be started.

8. ⚠️ If the vehicle is equipped with a start-stop system, restarting the engine after automatic shutdown shall not require an additional breath test by the Senseair Go.
9. Switch off the ignition, exit the vehicle, and lock it.
10. The Senseair Go shall either switch off immediately or continue counting down the remaining Free Start Time, depending on configuration and installation.
11. The engine can be restarted without providing another breath sample within the Free Start Time or, in SafeStart configuration, with identification and a valid green time.
12. If the engine is not restarted, the Senseair Go switches off automatically once the Free Start Time has expired.
13. After expiration of the Free Start Time, the engine can only be started again after a successful breath test.
14. In SafeStart configuration, the active user session shall be terminated (log-out).

5. Related documents

Product documentation, including the user manual and product specification, is available at www.senseair.com (search: Senseair Go).

IMPORTANT NOTICE

1. Senseair reserves the right to make changes to the information contained in this document without notice. When you consider any use or application of Senseair product stipulated in this document ("Product"), please make inquiries the sales office of Senseair or authorised distributors as to current status of the Products.
2. All information included in this document are provided only to illustrate the operation and application examples of Senseair Products. Senseair neither makes warranties or representations with respect to the accuracy or completeness of the information contained in this document nor grants any license to any intellectual property rights or any other rights of Senseair or any third party with respect to the information in this document. You are fully responsible for use of such information contained in this document in your product design or applications. Senseair ASSUMES NO LIABILITY FOR ANY LOSSES INCURRED BY YOU OR THIRD PARTIES ARISING FROM THE USE OF SUCH INFORMATION IN YOUR PRODUCT DESIGN OR APPLICATIONS.
3. The Product is neither intended nor warranted for use in equipment or systems that require extraordinarily high levels of quality and/or reliability and/or a malfunction or failure of which may cause loss of human life, bodily injury, serious property damage or serious public impact, including but not limited to, equipment used in nuclear facilities, equipment used in the aerospace industry, medical equipment, equipment used for automobiles, trains, ships and other transportation, traffic signaling equipment, equipment used to control combustions or explosions, safety devices, elevators and escalators, devices related to electric power, and equipment used in finance-related fields. Do not use Product for the above use unless specifically agreed by Senseair in writing.
4. Though Senseair works continually to improve the Product's quality and reliability, you are responsible for complying with safety standards and for providing adequate designs and safeguards for your hardware, software and systems which minimise risk and avoid situations in which a malfunction or failure of the Product could cause loss of human life, bodily injury or damage to property, including data loss or corruption.
5. Do not use or otherwise make available the Product or related technology or any information contained in this document for any military purposes, including without limitation, for the design, development, use, stockpiling or manufacturing of nuclear, chemical, or biological weapons or missile technology products (mass destruction weapons). When exporting the Products or related technology or any information contained in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. The Products and related technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Please contact Senseair sales representative for details as to environmental matters such as the RoHS compatibility of the Product. Please use the Product in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Senseair assumes no liability for damages or losses occurring as a result of noncompliance with applicable laws and regulations.
7. Resale of the Product with provisions different from the statement and/or technical features set forth in this document shall immediately void any warranty granted by Senseair for the Product and shall not create or extend in any manner whatsoever, any liability of Senseair.
8. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Senseair.

www.senseair.com